TOOL USE INSTRUCTION		
	TOOL NUMBER	TSN01560-300-C
RIVIAN	TITLE	R1 HUB BOLT - TORQUE KIT
	REV - DATE	REV C - 3/28/2025

### **CONTENTS**

**OVERVIEW** 

**SAFETY** 

**INITIAL SETUP** 

**TOOL USE INSTRUCTION** 

**MAINTENANCE & STORAGE** 


**SERVICE & REPLACEMENT PARTS** 

**TROUBLESHOOTING** 

**SYMBOL GLOSSARY** 

#### **TOOL FUNCTION:**

KIT USED TO TORQUE R1 HUB BOLTS WITH AXLES INSTALLED REFERENCE: RCA-18-24-001-1 TIGHTEN HUB TO KNUCKLE FASTENERS






### **LABOR CODES**

RCA-18-24-001-1: TIGHTEN HUB TO KNUCKLE FASTENERS

# **OTHER TOOLS REQUIRED**

TSN00048-100-A - 3/8" DIGITAL TORQUE WRENCH





### **COMPONENT GUIDE**

ITEM	QTY	RIVIAN TOOL ID	DESCRIPTION
1	1	TSN01556-300-B	LOW PROFILE R1 HUB SOCKET, 18MM
2	1	TSN01586-100-A	3/8" DRIVE IMPACT WOBBLE EXTENSION SET





# **WARNING**

Do not perform procedure if tool is damaged or missing parts. Consult the Rivian Service Tool Catalog for replacement components.

Failure to follow guidelines outlined in this document could result in injury and/or property damage.

#### **SAFETY GUIDELINES**

1	Use socket for specified RCA only.
2	If procedure is performed on the ground, ensure vehicle is on a flat surface with the parking brake engaged.
3	Ensure socket is fully seated on HUB bolt before torque is applied.
4	Be aware of potential pinch points between fingers and suspension components before torque is applied.



#### **INITIAL SETUP**

All-Terrain From the center display, set vehicle to: Q) Rock Crawl 1 **OFF-ROAD** mode HIGHEST ride height 0 From the center display, select: 2 Vehicle -> Service -> Tire Change Remove lower undershields as needed to 3 gain better access to the rear hub bolts




Turn front wheels all the way to the left to provide access to the 2x FWD hub bolts on the drivers side and 2x RR hub bolts on the passengers side.

Using the custom 18mm socket and a wobble extension (3" or 12"), torque the hub bolt to spec.

You can stack any standard extension after the wobble as needed to gain better leverage or clear suspension components.

# **IMPORTANT**

Refer to service manual procedure for torque values.







1



Turn front wheels all the way to the right to provide access to the 2x RR hub bolts on the drivers side and 2x FRT hub bolts on the passengers side and repeat torque procedure.







2




Moving to the rear axle, use the custom 18mm socket and a wobble extension (3" or 12"), torque the hub bolt to spec.

Repeat procedure for both driver and passengers side.

# **IMPORTANT**

Refer to service manual procedure for torque values.









3



#### **MAINTENANCE & STORAGE**

TASK	FREQUENCY
Inspect socket for signs of damage or wear. Replace as needed.	Before Each Use
Put tools back in provided tool case to ensure all components are accounted for and available for the next technician to use.	After each use
Ensure tool is free of moisture and/or chemicals prior to storage.	After each use

# NOTE

Tools are distributed by Rivian Service Tooling Team to perform RCA-18-24-001-1


For replacement parts, contact ServiceToolEngineering@rivian.com



### **SERVICE & REPLACEMENT COMPONENTS**

# FOR OTHER ITEMS NOT SHOWN, CONTACT RIVIAN SERVICE TOOL ENGINEERING

ITEM	DESCRIPTION	SUPPLIER + PART NUMBER
1	LOW PROFILE R1 HUB SOCKET, 18MM	AGA - TSN01556-300-B (SPECIAL ORDER, CONTACT TOOLING TEAM)
2	3/8" DRIVE IMPACT WOBBLE EXTENSION SET	CAPRI - CP58150
3	ADJUSTABLE LENGTH STORAGE TUBE	MCMASTER-CARR - 5433N36







# **WARNING**

Risk of minor injury

### **REVISION LOG**

REV	DATE	CHANGE DESCRIPTION
А	11/08/2024	Initial release
В	1/22/2025	Update to capture changes to the BOM at the Rev-B design of the kit. Added replacement parts sheet.
С	3/28/2025	Update to capture changes to BOM at the Rev-C design of the kit.

